


















ĮLEIDŽIAMŲ KONVEKTORIŲ FH MONTAVIMO INSTRUKCIJA

INSTALLATION INSTRUCTIONS OF TRENCH HEATERS FH

ИНСТРУКЦИЯ ПО МОНТАЖУ ВНУТРИПОЛЬНЫХ КОНВЕКТОРОВ FH






VIENO FH PAJUNGIMAS PRIE PATALPOS TERMOSTATO
CONNECTING ONE FH TO ROOM THERMOSTAT
ПОДКЛЮЧЕНИЕ ОДНОГО FH К КОМНАТНОМУ ТЕРМОСТАТУ

PATALPOS TERMOSTATAS **TW24**
 ROOM THERMOSTAT **TW24**
 ТЕРМОСТАТ ПОМЕЩЕНИЯ **TW24**


ILEIDŽIAMAS GRINDINIS KONVEKTORIUS **FH**
 TRENCH HEATER **FH**
 ВНУТРИПОЛЬНЫЙ КОНВЕКТОР **FH**



KELIŲ FH PAJUNGIMAS PRIE PATALPOS TERMOSTATO
CONNECTING MULTIPLE FH TO ROOM THERMOSTAT
ПОДКЛЮЧЕНИЕ НЕСКОЛЬКИХ FH К КОМНАТНОМУ ТЕРМОСТАТУ

PATALPOS TERMOSTATAS **TW24**
 ROOM THERMOSTAT **TW24**
 ТЕРМОСТАТ ПОМЕЩЕНИЯ **TW24**

ILEIDŽIAI GRINDINIAI KONVEKTORIAI **FH** (IKI 30 VNT.)
 TRENCH HEATERS **FH** (UP TO 30 PCS)
 ВНУТРИПОЛЬНЫЕ КОНВЕКТОРЫ **FH** (ДО 30 ШТ.)



EL. PAJUNGIMO SCHEMA | WIRING DIAGRAM | СХЕМА ПОДКЛЮЧЕНИЯ

